



1. Fix the left and right holders, baseplate with screws.

2. Fix the AD board, four metal meshes with screws, then fasten them.